











40458

Straightforward elegance. **cubique** 40458 offers a very extensive range of models, which allows a wide variety of combinations for every space requirement. The unmistakable lounge furniture has piping on the outer edges, which elegantly draws the eye and emphasises the design.







40458

ARMCHAIRS



Loveseat



M100 Loveseat



140/104/66/39 fire protection = BK15 (surcharge)

160/104/66/39 fire protection = BK18 (surcharge)

M120 Loveseat

180/104/66/39 fire protection = BK22 (surcharge)

INTERMEDIATE ELEMENTS



M80K element without armpart

81/104/66/39 fire protection = BK14 (surcharge)



element without armpart





large sofa without armpart

161/104/66/39 fire protection = BK24 (surcharge)



armpart

201/104/66/39 fire protection = BK27 (surcharge)



N100K large sofa without

SOFAS







N100 large sofa



N120 large sofa

220/104/66/39 260/104/66/39 fire protection = fire protection = BK25 (surcharge) BK28 (surcharge)

300/104/66/39 fire protection = BK35 (surcharge)

FREESTANDING ELEMENTS WITHOUT ARMPART



M81K element without armpart freestanding

81/104/66/39

fire protection =

BK14 (surcharge)



M101K element without armpart freestanding

101/104/66/39

fire protection =

BK17 (surcharge)



large sofa without armpart freestanding

161/104/66/39

fire protection =

BK24 (surcharge)



large sofa without armpart freestanding

201/104/66/39 fire protection = BK27 (surcharge)

ELEMENTS WITH ARMPART RIGHT



element with armpart

110/104/66/39

fire protection =

BK14 (surcharge)



M100R element with armpart

130/104/66/39

fire protection =

BK17 (surcharge)



M120R element with armpart

150/104/66/39

fire protection =

BK21 (surcharge)



N80R large sofa with armpart

190/104/66/39

fire protection =

BK24 (surcharge)



N100R large sofa with armpart

230/104/66/39

fire protection =

BK27 (surcharge)



large sofa with armpart

270/104/66/39 BK34 (surcharge)



fire protection =



www.schillig-objects.com

40458

ELEMENTS WITH ARMPART LEFT





110/104/66/39

fire protection =

BK14 (surcharge)



M100L element with armpart

130/104/66/39

fire protection =

BK17 (surcharge)



M120L element with armpart

150/104/66/39

fire protection =

BK21 (surcharge)



N80L large sofa with armpart

190/104/66/39

fire protection =

BK24 (surcharge)



N100L large sofa with armpart

230/104/66/39

fire protection =

BK27 (surcharge)



N120L large sofa with armpart

270/104/66/39 fire protection = BK34 (surcharge)

END ELEMENTS LEFT

END ELEMENTS RIGHT



one arm chaise



K120L one arm chaise

150/164/66/39 fire protection = BK22 (surcharge)

150/164/66/39 fire protection = BK22 (surcharge)

FREE-STANDING ELEMENTS RIGHT



freestanding element



freestanding element



freestanding element



N81R large sofa with armpart freestanding



N101R large sofa with armpart freestanding



N121R large sofa with armpart freestanding



one arm chaise freestanding

110/104/66/39
fire protection =
BK14 (surcharge)

130/104/66/39 fire protection = BK17 (surcharge)




190/104/66/39 fire protection = BK24 (surcharge)






150/164/66/39



www.schillig-objects.com



OBJECTS

40458

FREE-STANDING ELEMENTS LEFT



freestanding element



M101L freestanding element



M121L freestanding element



N81L large sofa with armpart freestanding



part freestanding

N121L large sofa with arm-







one arm chaise freelarge sofa with armpart freestanding standing



110/104/66/39 fire protection = BK14 (surcharge)

130/104/66/39 fire protection = BK17 (surcharge)

150/104/66/39 fire protection = **BK21** (surcharge)

190/104/66/39 fire protection = BK24 (surcharge)

230/104/66/39 fire protection = BK27 (surcharge)

270/104/66/39 fire protection = BK34 (surcharge)

fire protection = BK22 (surcharge)

OTTOMANS & ACCESSORIES



G120

large ottoman quilting



decorative pillow with



decorative pillow without quilting



UF60. pillow w/ flattering tuck

120/60/39/0 fire protection = BK6 (surcharge)

60/60/0 fire protection = **BK1** (surcharge)

60/60/0 fire protection = **BK1** (surcharge)

68/68/0 fire protection =

BK1 (surcharge)



40458



Simply nice

The discreetly used, striking tuck at the outside edges of the upholstery provides a unique look.



"Flame retardant"

Optionally, the "flame-retardant" version of this model can be ordered (art. no. = BK ..). **Please specify when ordering.**

ORDER INFORMATION

Back sides of sofas:

All pieces are genuinely upholstered at the

Positioning diagram:

Please send us a positioning diagram, depending on the many different variations available.

Connecting sides:

For a surcharge, the connecting sides can be supplied in the original cover instead of stretch

fabric.

Seam appearance:

Decorative, felled or double seams may appear different in fabric and leather versions. For manufacturing reasons, seams may be left out of the fabric version or replaced with simple seams.

Two-piece sofas:

The sofas N120 and N120R/L consist of 2 parts

(M120R and M120L) that are connected to element connectors.

All of the dimensions given are approximate dimensions in cm in width/depth/height/seat height. We reserve the right to make changes.

Seat depth: approx. **66 cm**Seat depth one arm chaise: approx. **127 cm Model-related feature:**

The upholstery is deliberately processed casually to create a certain visual appearance. Waving is not a quality defect, but a model-related feature that ensures optimum seating comfort.

Please note:

Special designs may be made on some elements in return for an extra charge. Please consult us. We are happy to make your

dreams come true.

Digital fabric/leather and colour samples:

The visual appearance of the covers and colour samples may vary, samples in accordance - colour and structure deviations possible.

www.schillig-objects.com





LEGS



Plastic glide

F 00

cubique

40458

ORDER CHECKLIST

- Structure and cover (order information)
- Flame retardant version (surcharge)
- Ottomans
- Pillows
- Positioning diagram



40458

CONFIGURATION EXAMPLES





40458

FRAME STRUCTURE

- **1. Frame** metal frame foamed in cold foam
- **2. Seat and back upholstery structure** foamed metal frame with diolen cover

Upholstered furniture from passion.

For almost 75 years, this passion has led to the creation of high-quality and special pieces of furniture and designer furniture - sofas that combine elegant and contemporary design with first-class comfort. We stand for craftsmanship, trend-setting ideas, appealing design and know-how from Germany. The result is upholstered furniture with guaranteed first-class comfort and attention to detail. When selecting the materials used, we pay attention to sustainability and the conservation of resources.

- Traditional craftsmanship down to the last detail
- High-quality, environmentally friendly materials
- Careful & precise workmanship
- Cooperation with renowned furniture designers
- Production according to DIN & RAL quality guidelines of the Deutsche Gütegemeinschaft Möbel e.V.
- Regularly tested product quality "Made in Germany"
- Development at the Upper Franconian location in Ebersdorf near Coburg
- Carefully selected fabric and leather cover collections in many colours for a wide range of requirements.

W.SCHILLIG objects

GmbH & Co. KG
Am Weinberg 20 - 22
96237 Ebersdorf bei Coburg
GERMANY
Telephone: +49 9562 37-0
Telefax: +49 9562 37-500
E-Mail: info@schillig-objects.de











www.schillig-objects.com

